









1		2		3		4	
A	<div>2021-05-04</div> <div>TH221A_MG82F6B001_6B08_6B104_SOP16_EV_V10>>> V11</div> <div>add D14 -- IN5817(SMA & SOD323)</div> <div>change D1, D5 IN5817 footprint >>>(SMA & SOD323) duble lay</div> <div>change C4,C5,C6,C9,C11,C12,C13,C14 4.7uF footprint 0603C >>> 0805C</div>						A
B	<div>2021-12-08</div> <div>TH221A_MG82F6B001_6B08_6B104_SOP16_EV_V11>>> V111</div> <div>1. 換micro USB JACK_USB_SMD290X220P065 >>> USB_MICRO_7.X6P065</div> <div>2. 右半邊M_LINK PCB LAYOUT & SCH 要直接copy TH197B_V111(要共用銅板)</div>						B
C	<div>2022-03-11</div> <div>1. J19 pin1 & pin3 net 互換 PCB 上方 pin1 接GND 下方 pin3 接VDUT</div> <div>2. D11 , D12(1N5817) to U2-13, U2-14</div>						C
D					<div><div>Title</div><div><div>Size</div><div>A4</div></div><div><div>Date:</div><div>2022/3/17</div></div><div><div>File:</div><div>D:\DXP\.\TH221A NOTE.SchDoc</div></div><div><div>Number</div><div></div></div><div><div>Revision</div><div></div></div><div><div>Sheet of</div><div></div></div><div><div>Drawn By:</div><div></div></div></div>		D
1		2		3		4	