

**ICE Interface****RST Pin Ctrl****Tool Option**

J3 Open: Disable VCP.
J3 Short: Enable VCP.

